LOWER OVEN PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)

30" BUILT−IN ELECTRIC
DOUBLE OVEN
STD−CLEAN LOWER
SELF−CLEAN UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER OVEN PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Trim, Side
	4450850	RH Black
	4450851	RH White
	4450853	LH Black
	4450854	LH White
		Screw
	4449747	Black Model
	4449041	White Model
4	4448520	Bumper, Door
7	4451166	Partition
	4449809	Screw
9	4449009	Tube, Vent
	4449154	Screw
10	4451050	Fan & Bracket Assy.
	4449809	Screw
11	4450706	Oven Light Assy
14	4450417	Frame, Front
	4449040	Screw
15	4450493	Gasket, Door
19	4450542	Support, Insulation
25	4450528	Side, Chassis
		(R.H. & L.H.)
	4449809	Screw
26	4454729	Back, Chassis
	4449809	Screw
27		Liner, Oven
		(Not serviceable)
29	4450026	Sensor
	4449154	Screw
31	4450819	Switch, Door
32	4449369	Vent Box Assy.
	4449809	Screw
37	4451354	Fuse−Thermal
	4449809	Screw
43	4450527	Base, Chassis
	4449154	Screw
49	4448933	Retainer, Gasket
	4449154	Screw
50	4450544	Cover, Back
	4449809	Screw
51		Trim, Bottom
	4448477	Black Model
	4448478	White Model
	4450289	Screw
53	4449845	Support, Bracket
	4449809	Screw

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

	4449316	Insulation, Wrap
	4450365	Insulation, Back

UPPER OVEN PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER OVEN PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
4	4448520	Bumper, Door
6	4451039	Divider, Vent
	4449809	Screw
7	4451166	Partition
	4449809	Screw
9	4449009	Tube, Vent
	4449154	Screw
11	4450706	Oven Light Assy
14	4450417	Frame, Front
	4449040	Screw
15	4449372	Gasket, Door
19	4450542	Support, Insulation
	4449809	Screw
21		Rail, Side
	4450581	Right Side
	4450582	Left Side
	4448444	Grommet
	4449154	Screw
22	4451036	Shield, Latch
	4450289	Screw
23	4450051	Deflector, Latch
	4449809	Screw
24	4454710	Latch Assy
	4449809	Screw
25	4450528	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4454729	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
29	4450026	Sensor
	4449154	Screw
31	4450819	Switch, Door
32	4449369	Vent Box Assy.
	4449809	Screw
34	4449052	Vent, Center
37	4450934	Thermostat (TOD) (Temp.) SPST
49	4448933	Retainer, Gasket
	4449154	Screw
50	4450544	Cover, Back
	4449809	Screw
53	4449845	Support, Bracket
	4449809	Screw
54	4451002	Spacer, Harness
	4449809	Screw

FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

	4449316	Insulation, Wrap
	4450365	Insulation, Back

LOWER OVEN DOOR PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4450429	Door Liner
2	4450935	Plug, Door
3	4449258	Glass, Inner
6	4451172	Hinge, Door
	4449743	Screw
12		Door Glass, Outer
	4450691	Black Model
	4450692	White Model
13		Door Handle
	4448854	Black Model
	4448855	White Model
14	4450813	Bracket, Handle
	4451040	Screw
20	4450423	Retainer, Glass
	4449809	Screw
21	4450837	Seal, Door Top
22	4450838	Seal, Side
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model

UPPER OVEN DOOR PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1	4450429	Door Liner
2	4451174	Hinge, Door
	4449743	Screw
3	4449259	Glass, Inner
4	4448680	Insulation, Top and Bottom Door
5	4450470	Retainer, Glass
	4449809	Screw
7	4449263	Glass, Inner (2)
9	4449031	Retainer, Glass
	4449809	Screw
12		Door Glass, Outer
	4450691	Black Model
	4450692	White Model
13		Door Handle
	4448854	Black Model
	4448855	White Model
14	4450813	Bracket, Handle
	4451040	Screw
18	4448707	Insulation, Sides
19	4450362	Shield, Heat
	4449809	Screw
20	4450423	Retainer, Glass
	4449809	Screw
21	4450837	Seal, Door Top
22	4450838	Seal, Side
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model

INTERNAL OVEN PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
2	4448698	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4448696	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
1		Control Panel Assy. W/Membrane Switch
	4451301	Black Model
	4451302	White Model
2	4451032	Gasket, Control Panel
	4449899	Screw
	4159465	Screw
3	4448876	Microcomputer
	4449745	Screw

LITERATURE PARTS

LIT4450411	Installation Instructions
LIT4450568	Use & Care Guide (Oven)
LIT4454767	Tech Sheet (Oven)

TOP VENTING PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
		NOTE: The screws and nuts required to attach a part are listed immediately following that part.
3	4450920	Blower,Upper/Lower
4	3182384	Foam, Block
6	4450367	Exhaust Duct
	4449809	Screw
11	4449868	Block, Terminal
	3196181	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Top
	4448371	Right
	4448372	Left
	4449809	Screw
	4449154	Screw
15	4450658	Back, Control
	4449809	Screw
16	4450551	Cover, Top Rear
	4449809	Screw
18	4450554	Cover, Top Front
	4449809	Screw
19	4450545	Bracket, Blower
	4449809	Screw

OPTIONAL PARTS

For Models:RBD305PDB3, RBD305PDQ3
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
		PAINT, TOUCH−UP (1/2oz.)
	72017	White
	261869	Cord Brown
	72032	Black
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
		SPLICING WIRES−−25FT. LENGTH
	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
		WIRING HARNESS PARTS
	4450951	Harness, Wire S/C (Door Switch)
	488366	Clamp
	4449809	Screw
	4454709	Harness, Wire (Latch)
	4450298	Harness, Wire STD (Door Switch)
	488366	Clamp
	4449809	Screw
	4451162	Harness, Wire (Main)
	4450953	Conduit, Double
	4450800	Screw, Ground
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450814	Fuse Assy (Service Only)
		Miscellaneous
	814381	Pin Hinge Kit
	814387	Roll Tape, Exhaust Duct
	4448950	Screw, Install (4)